

CASTER FORK REPLACEMENT

Tools Needed:

- 5 mm hex wrench – Small flathead screwdriver
- 15 mm open-ended box wrench – 19 mm



Step 2: Use the 5 mm hex wrench to remove bolt (circled in red) then remove caster wheel. (Use screwdriver to pry caps off both sides)



Step 4: Install new caster fork to frame (reverse step 3). Next, reinstall caster wheel to caster fork (reverse step 2).



Step 1: Use the flathead screwdriver to pry the caster wheel cap off caster fork.



Step 3: Use the 15 mm wrench and the 19 mm socket to unscrew bolt (circled in red) then remove caster fork from frame.



Step 5: Reinstall all caps (one that sits atop caster fork and the two that cover nut and bolt).

