

Part Identification

- Ultrasonic Sensor - CaddyBelt - Handset



Step 1: Insert CaddyBelt's micro USB end into the handset.



Step 2: Insert the other end of CaddyBelt into the Ultrasonic Sensor (You can plug it into either side, the left or right).



Step 3: Turn on the handset. Once connected, the Ultrasonic Sensor light will turn green and the handset will be flashing green lights.



Step 4: Power on the CaddyTrek and position yourself within 2 feet of unit (see tips below).



Step 5: Attach the handset to your back and the CaddyBelt sensor to the front of your body.



Step 6: Press and hold the LEFT directional button (Follow Mode).



Step 7: Engage Follow Mode



1. Slowly turn your body 180 degrees, start walking, and Follow Mode will auto. engage.
 - a. Hold down the Follow button until you hear one short beeps.
 - b. Start walking and the CaddyTrek will follow.
 - c. To disengage, press the STOP or FOLLOW button,
2. To use the CaddyBelt in dual mode (Marching and Follow), you will need to start in FL mode.
3. To change to Marching, turn your body 180 degrees and the cart will automatically start marching in front of you.
4. To disengage, push the FOLLOW or STOP button.
5. If your unit is not engaging, ensure that the Ultrasonic Sensor light is green & sensors are not obstructed