

### Tools Needed:

- A small flathead screwdriver



**Step 1:** Using the small flathead screwdriver and pry caster wheel cap off.



**Illustration:** Caster mount cap removed.



**Step 2:** Insert the replacement caster mount cap and secure it tightly.



**Step 3:** Push in tightly making sure it's secured.

