

### Tools Needed:


- Phillips screwdriver
- Cordage that is strong enough to pull the sensor cable (string, fish tape, etc).



**Step 2:** Unscrew & detach sensor from E-box.



**Step 4:** Install new sensor wire. Loop end of sensor wire. Fold cordage (to grab sensor wire) and insert into sensor tube.



**Step 1:** Unscrew and remove the (5) screws and (5) wire clasps that secure the sensor wire to frame then remove the sensor tube plug (marked by arrow).



**Step 3:** Remove sensor in the direction that is shown and put aside. Get replacement.



**Step 5:** Pull the sensor wire through the sensor tube (using the cordage) all the way until sensor wire is completely inserted.



**Step 6:** Push the sensor end into the tube in the direction of the red arrow. Check that the holes align to the knobs on the sensor end.



**Step 7:** Install the frame's sensor tube plug. Note the direction the gap is facing on the frame's sensor plug.



**Step 8:** Screw on the sensor plug indicated by the red circle.



**Step 9:** Reinstall the (5) screws and (5) clasps. After installation, check for slack or slippage.



**The End:** Congratulations, you have successfully replaced the sensor!