

## UPPER JOINTS ASSEMBLY REPLACEMENT

### Tools Needed:

- Phillips screwdriver or
- 3 mm Hex Head wrench
- Rubber mallet (Optional)



**Step 1:** Using the Phillips screwdriver, remove the (4) top screws on upper joints.



**Step 2:** Loosen the joints (red arrow) and squeeze together (red circle) to get crews out.



**Step 3:** Using the rubber mallet, gently tap upward to detach the pull handle.



**Step 3 Illustration:** Pull handle removed.



**Step 4:** Remove the (4) screws on lower part of upper joints indicated by the red arrows.



**Step 5:** Detach the upper joint assembly as shown below.



**Step 5 Illustrations:** Upper joint assembly removed.



**Step 6:** Obtain and install the new upper joint assembly and secure it to the frame.



**Step 7:** Reinstall the pull handle back into place.



**Step 8:** Tighten all (8) screws for the upper joint assembly.



**The End:** Congratulations, you have successfully replaced the upper joint assembly!